


D Montageanweisung
F Instructions d'installation
I Istruzioni di montaggio
NL Installatievoorschrift
DK Installationsinstruktus
N Installationsinstruktioner
FIN Asennusohje
S Installationsinstruktioner
E Instrucciones de montaje


ML6420A30xx/ML7420A60xx

Electric Linear Valve Actuators


INSTALLATION INSTRUCTIONS




A1-A6: Installation




A1




A2




A3




A4a: ML6420A3007, A3023 (24 V)



A4b: ML6420A3015, A3031 (230 V)



MU1B-0234GE51 R0216E



Subject to change without notice.

MU1B-0234GE51 R0216E