sales@prom-elec.com

Electronic-Pneumatic Transducers

SPECIFICATION DATA



GENERAL

The RP7517A, B Electronic-Pneumatic Transducers are used in electronic-pneumatic control systems to convert a proportional electric output signal from a controller into a direct-acting, proportional pneumatic signal.

The RP7517A is powered by the control signal. It is available with a cover or without a cover for panel mounting (the panel model has a higher pressure output than the cover model and is approximately equal to the RP7517B in branchline buildup).

The RP7517B (used with Excel) has an internal amplifier and requires a lower current control signal. It is available with a cover or without a cover for panel mounting.

FEATURES

- Screw mounting or snap rail (models with cover)
- Factory calibrated
- Dual barb fittings
- High accuracy



Copyright © 1991 Honeywell Inc. • All Rights Reserved

DESCRIPTION

The RP7517A, B Electronic-Pneumatic Transducers are used in electronic-pneumatic control systems to convert a proportional electric output signal from a controller into a direct-acting, proportional pneumatic signal.

The RP7517A is powered by the control signal. It is available with a cover or without a cover for panel mounting (the panel model has a higher pressure output than the cover model and is approximately equal to the RP7517B in branchline buildup). The RP7517B (used with Excel) has an internal amplifier and requires a lower current control signal.

SPECIFICATIONS

Models:

- □ RP7517A1009: 2-wire, with cover, without internal amplifier. Typically used with DeltaNet MicroCel[™] and MicroniK 100.
- □ RP7517A1017: 2-wire, without cover, without internal amplifier, higher pressure buildup than the RP7517A1009. Typically used with R7044D, E.
- □ RP7517B1016: 3-wire, with cover, with internal amplifier. Typically used with Excel, R7044A-E, EXCEL 5000TM system applications.
- □ RP7517B1024: 3-wire, without cover, with internal amplifier. Typically used with Excel, R7044A-E, EXCEL 5000™ system applications.

Ambient Operating Limit:

Temperature: 41 to 131F (5 to 55C) Humidity: 5 to 95% rh

Storage: -22 to 158F (-30 to 70C)

Power Supply:

RP7517A: None

RP7517B: 24V, +10% -15%, 50/60 Hz

Power Consumption:

RP7517A1009: 16 mA at 12V dc RP7517A1017: 16 mA at 11.5V dc

RP7517B1016: 1.7 VA

Input Signal:

RP7517A: 2 to 10V dc

RP7517B: 2 to 10 dc (up to 0.1 mA)

Mounting:

Models with covers have snap (DIN) rail capability

Output Pressure:

Model	Nominal Range psi (kPa) at 2 to 10V dc	Nominal Low End psi (kPa) at 0V dc	Nominal High End psi (kPa) with 18 psi (125 kPa) Main Pressure
RP7517A1009	3 to 15 (20 to 103)	0.5 (3.5)	16.0 (110.0) at 12V dc
RP7517A1017			17.0 (117.2) at 12V dc/16.0 (110.0) at 11V dc (min)
RP7517B1016			
RP7517B1024			

NOTE: Excel 500, 100, and 80 provide a maximum of 11V dc output to the transducer.

Main Air Pressure:

18 psi (125 kPa)

Maximum Safe Air Pressure:

29 psi (200 kPa)

Air Consumption:

0.025 scfm (11/7 ml/s)

Air Capacity:

0.45 scfm (211 ml/s)

Air Connections:

Dual barb-fittings for: 1/4-in. (6-mm) O.D.

01

5/32-in. (4-mm) O.D. polyethylene tubing

Electrical Connections:

RP7517A1009: 30-in (762-mm) lead wires

RP7517A1017: Screw terminals for 14 to 22 gage wire

RP7517B1016: 30-in. (762-mm) lead wires

RP7517B1024: Screw terminals for 14 to 22 gage wire

Calibration:

Factory calibrated

NOTE: RP7517 must be mounted vertically within 5 degrees

to maintain factory calibration.

77-5014

Dimensions In Inches (Millimeters): Wiring: 2-7/16 (62) -2 (51.5) BLUE Y 2-10V SIGNAL RP7517A1009 BLACK _ ⊥ соммом 0 М В 0 Y 2-10V SIGNAL 3-5/8 (92) L COMMON RP7517A1017 MODEL WITH COVER 2 М В 2-7/16 (62) 2 (50.8) Y 2-10V SIGNAL 1-7/8 (47.7) RP7517B1016 BLACK — ⊥ COMMON BROWN ~ 24V AC φ Ф М Y 2-10V SIGNAL 3-3/8 (85.8) ⊥ COMMON ~ 24V AC RP7517B1024 MODEL WITHOUT COVER М В 2 TERMINALS ON RP7517A1017 3 TERMINALS ON RP7517B1024 C5402-1 C5160-2

sales@prom-elec.com

3

77-5014

By using this Honeywell literature, you agree that Honeywell will have no liability for any damages arising out of your use or modification to, the literature. You will defend and indemnify Honeywell, its affiliates and subsidiaries, from and against any liability, cost, or damages, including attorneys' fees, arising out of, or resulting from, any modification to the literature by you.

Home and Building Control

Honeywell Inc. Honeywell Plaza P.O. Box 524 Minneapolis MN 55408-0524

Honeywell Latin American Division

Miami Lakes Headquarters 14505 Commerce Way Suite 500 Miami Lakes FL 33016 **Home and Building Control**

Honeywell Limited-Honeywell Limitée 740 Ellesmere Road Scarborough Ontario M1P 2V9

Honeywell Europe S.A. 3 Avenue du Bourget B-1140 Brussels Belgium Honeywell Asia Pacific Inc.

Room 3213-3225 Sun Hung kai Centre No. 30 Harbour Road Wanchai Hong Kong

Honeywell

